

# Stouffer grey step wedge for the exposure of photoimagable coating materials

## Stouffer grey step wedge for the exposure of photoimagable coating materials

- Stouffer 21-step wedge / grey step wedge
- Polyester strips with different accurately defined density steps
- for determination of exposure parameters